TS 1005 .U5







HANDBOOK OF SHOE FACTORY ENGINEERING

USMC

UNITED SHOE MACHINERY COMPANY

BOSTON

MASS.

Prepared and Issued by the Department of Agencies

75,005

Copyright, 1916, by United Shoe Machinery Company Boston, Mass.

MMR -5 1919

Oci. 4514371

ma 1

INTRODUCTION

The material and data contained within this little book are the result of many years' investigation and experience in the designing and equipping of modern factories—particularly as applied to the manufacture of shoes.

The remarkable economies and increased efficiency to be obtained by conducting manufacturing operations in buildings especially designed to meet the particular requirements of the industry with full consideration paid to the modern development of those important elements which have to do with light, heat, power, equipment and interior organization, have but recently attracted the attention of shoe manufacturers.

The remarkably rapid growth of the shoe manufacturing industry during the past fifteen years has afforded shoe manufacturers but slight opportunity for investigation in this important field, the increased demand for more space being ordinarily met by building additions to old plants. In a constantly increasing number of instances, however, this expedient has reached its logical limit and brought those concerned in the factory management face to face with the building problem.

Anticipating this tendency in the evolution of the industry, the experts of the Department of Agencies have from its inception been closely in touch with every phase of its development and plans for many of the factories of most modern construction have been prepared by them.

The services and experience of these experts are at the disposal of the Company's patrons and the constantly increasing demand for data in this connection has brought this little book into being.

With a full realization of the proportions of the problem and the impossibility of treating in more than a general way at this time so vast a subject, the important information it contains is submitted as a basis for more detailed and thoughtful consideration.

AN IDEAL SHOE FACTORY

THE BUILDING

If no disturbing conditions or requirements intervened and the manufacturer was able to accept the following specifications (detailed explanation of which appears on another page), he would have a factory, ideal in construction and arrangement. It is seldom indeed that this ideal condition can be found, but the details should be modified only as necessity requires. The ideal factory would conform to this schedule:—

Shape: Rectangular

Width: 40 to 50 feet inside

Length: As per capacity, up to 1,000 feet

Number of Floors:

3 Floors and Basement

Top Floor — Cutting and Upper Fitting Second Floor — Lasting and Making

Street Floor — Finishing, Dressing and Packing

Basement — Stock Fitting, Sole Leather Cutting and Storage

Altitude of Floors:

9 feet, 6 inches (minimum.)

11 feet, 6 inches (ideal)

Floor Strain:

150 pounds per square foot

Tower: One to every 300 or 400 feet. Located in the centre of side, 40 feet by 40 feet

Its function:

Elevators, stairways, toilets, coatrooms, etc.


Windows:

As many as possible

Sawtooth roof

Construction material:

Relative as to locality



away for shoemaking. With a sawtooth roof the steady north light makes the One row ofposts. Tower of ample size, leaving the manufacturing space straightcentral portion of top floor as light as the sides.

Cost; approximate.

Concrete — cost \$1.25 square foot

Brick - cost \$1.00 (150 pounds) square foot

Wood — cost \$.75 to \$.90 (150 pounds) square foot

Approximate number of feet necessary per pair of shoes:

Welts — 15 square feet

Turns — 15 square feet

McKay — 10 to 12 square feet

Standard Screw and Pegs — 10 to 12 square feet

Stitchdowns — 8 to 10 square feet

Offices:

Location:

Separate Building

End of building, first floor

Provision for Employees' Welfare:

Rest room, restaurant, recreation room, hospital, etc.

Storage for Material:

Separate building

Small supply of finished and raw stock in factory

Humidifying Room:

Important for the proper conditioning of sole leather, waxes, threads, counters, etc.


Size of room as per conditions.

In the consideration of a shoe manufacturing plant, the first problem which presents itself is: "What shape shall it be?"

Shape and "What is the best?" Years of experience

Size

have proven that a rectangular shaped building, from forty to fifty feet wide with the length up to the limit of one thousand feet, works out to the best advantage. Fifty feet in width is practically the limit for a factory where only one row of posts is desired for support in the middle, and fifty feet is preferable to forty, due to the fact that it allows ample room for the storage of shoes awaiting



ENDICOTT JOHNSON CO, "SCOUT" FACTORY, JOHNSON CITY, N. Y., 620 FEET LONG, SHOWING POSITION OF TOWERS

The building is of interest on account of its length and width, simplicity of design, steel super-structure with brick facing and the Dust Collecting System. Motor and Fans being on outside wall of building. their operation and gives plenty of aisle space for the incoming and outgoing racks. As it is well known that the central portion of a shoe factory is not light enough for machine operation, the rectangular shaped building should need no further defence.

Three stories and a basement is the best height for the building. If we add another floor, or floors, the strain becomes so great that the cost of construction increases materially. The best arrangement for the operation in three stories, due to the fact that the natural sequence of operations follow logically and there is, therefore, less handling of the shoes, is as follows:

Top Floor
Cutting
Upper Fitting
Packing
Second Floor

Street Floor
Finishing
Dressing
Packing
Offices

Lasting
Making

Basement
Stock Fitting
Sole Leather Cutting
Storage

The altitude of the floors should not be less than nine feet, six inches; and eleven feet, six inches is ideal. The latter Altitude

Altitude allows for better ventilation and light, and gives ample head room under the pulleys, belts, etc., for the operatives.

The tower in connection with any manufacturing plant, especially the shoe plant, is modern and a feature that, if

Tower properly located and designed, is well nigh indispensable. It should be on the outside, in the centre of the building if under five hundred feet in length, or there should be a tower for every three or four hundred feet. Forty feet square is the ideal size. By the use of this, or these towers for the location of elevators, stairways, toilets, coat rooms, etc., the main factory is left entirely for the purpose for which it was intended; viz — the manufacture of shoes.

When designing a factory as much window space as possible should be provided. There is no one who will argue that you can have too much light. The roof should be of the sawtooth construction, admitting the north light in order that the central portion of the room will be as well lighted as the sides. This allows for the best possible arrangement of the benches in the Upper Fitting Room.

There are three choices as to what is best to use for material in the construction of a shoe factory. Concrete is fire-proof, requires less upkeep and admits of the lowest rate of insurance, but costs more to construct in the beginning. It is possible with concrete to allow room for more window space than with any other material.

Brick, with the beam and girder construction is the second choice, at a little less figure than the concrete.

Wood is the last choice. It costs two-thirds as much as



LUPTON STEEL SASH FOR SIDE WALLS



POND CONTINUOUS SASH IN SAWTOOTH ROOF CONSTRUCTION

the concrete, but would require a high rate of insurance and constant repairs.

The location of the factory would influence materially the decision as to which of the three above types would be most desirable.

The prices of material will vary greatly in different sections of the country.

The offices, if possible, in a large manufacturing plant should be in a separate building, in order that they may be away from the noise and leave additional room for the manufacturing. If, however, the resources of the manufacturer are limited, the best place for the offices is on the street floor at one end of the building.

Most employers of labor in these modern times plan for their employees' welfare by the installation of rest rooms, Employees' hospitals, restaurants and recreation rooms, and in designing a new factory it would seem a mistake to leave this feature without consideration. It is hard to say what is the best location. If it were a city factory, a portion of the top floor would probably be the best, due to the fact that there would be more light and



HOSPITAL AT PLANT OF U. S. M. C. BEVERLY, MASS.

air, but if in the country perhaps the conveniences of a properly arranged basement might be more desirable.

The manufacturer of shoes should not use his manufacturing plant, for which he charges himself a fair rental rate, for the Storage of Material use of storage of material, and never should he carry in his plant more than a week's supply of raw material or finished goods. If it is necessary to stock material in large quantities, either finished or raw, a separate building or a rented loft should be arranged for at a much less cost than which he charges against himself for manufacturing.



ONE OF THE LOCKER AND WASH ROOMS AT U. S. M. CO. FACTORY

Provision for a suitable sized-room for the proper conditioning of leather should be arranged for in which a moistening or humidifying machine can be placed. This room should be located near the assembling department, and the soles, counters, etc., sent from there to the various departments as per the requirements.

DESCRIPTIVE DETAILS OF TEMPERING ROOM

It is beneficial in the conditioning of leather: — Welting, leather for soles, counter blanks, etc. — when the temper is once reached, to retain its mulled condition, without having



HUMIDIFYING ROOM IN FACTORY OF LUND & SWEET, AUBURN, ME.

recourse to wetting again, and to this end the tempering or humidifying room has been developed.

Any room of proper dimensions, available, will do, but better, a room may be built in that portion of the factory next to the assembling department, wood sheathing from the floor to the ceiling, and of such size to give the cubical contents necessary for the storage of a sufficient number of dozens of pairs of outer soles and other parts of the shoe which require tempering. This room should have proper window lights to permit the free circulation of air, and the entering of a proper amount of sunlight, and by means of the Humidor therein installed, the air may be kept at a certain percentage of humidity without depriving the leather of sunlight and fresh air, necessary to prevent "blooming" or "spuming" which commonly occurs when leather is stored in a dark room that

is more or less air-tight, causing of course, the quality to deteriorate.

The tempering room is arranged in a proper manner for the storing of leather by means of shelves of pre-determined width and height, and made of dowel-pin stock to permit of the proper circulation of air. This method of tempering assures splendid results, and the leather will be maintained at a proper working condition with a minimum effort, and a greater increase of value from the shoe-making standpoint.

A room 20 by 14 by 12 feet, contains 3,360 cubic feet; — the Humidifier being suspended from the ceiling, dropping 30 inches below the same, is operated by a small fan motor Electricity may be taken from any convenient electric light socket, and controlled by three-speed switch, so that the conditions may be readily controlled and varied as desired. The ½-inch water supply is taken from any convenient source and supplies the water jet, which vaporizes the water absorbed by the air passing thru the Humidifier, the maximum capacity of which is 26,000 cubic feet of air per hour, with a consumption of 35 gallons of water per hour (more or less); —at a pressure of 50 pounds—1 gallon per hour is absorbed by the air. The volume of water may be increased by maintaining a higher water pressure.

The water control is independent of the air circulation, and can be shut off entirely independent of the air current, which is desirable to maintain at all times, as it produces a uniform effect in the room, all the air of the room passing thru the Humidor, and being washed and properly humidified, thereby assuring a uniform circulation of the air and condition of the stock. A normal temperature of the room is only required, the air in the room being circulated seven times per hour.

AN IDEAL SHOE FACTORY

POWER AND LIGHT

If the manufacturer is not confronted by any unusual conditions and is free to choose, the facts presented in the following schedule regarding these two very important elements should receive most careful consideration:—

Requirements, (approximated):

20-25 pair Welts per H. P.

20-25 pair Turns per H. P.

30-40 pair McKays per H. P.

30-40 pair Nailed and pegged per H. P.

40-50 pair Stitchdowns per H. P.

Electric Motors:

550 volts, 3 phase, 60 cycle

Alternating Current

1800 R. P. M., all departments except Upper Fitting Room

1200 R. P. M. Upper Fitting Room

720 R. P. M. Exhaust Fan

Oil Switches for 5 H. P. Motors or less

Turbine, (Curtis Type):

For 100 H. P. requirements and over

For small requirements

Reciprocating steam engine and dynamo

Gas engine and dynamo

Purchased current

Cost of making power, light and heat 1½ to 2 cents per K. W.

Cost of buying power

Dependent on amount purchased from 1½-3½ cents per K. W.

For lighting alone in most districts the rate is three times greater than for power. Lighting:

General Illumination

Suitably powered lamps and shades at altitude of not less than 9 feet

Specific Illumination

As conditions warrant

Millwrighting:

Standard size of shafting $1-\frac{15}{16}$ inches in diameter and 60 foot lengths for all departments except upper fitting room; $1-\frac{3}{16}$ inches diameter for Upper Fitting Room. Sells Roller Bearings for shafting, reducing frictional load

to a minimum.

Hangers, 10 to 12 inch drop

Speed of shafting:

300 R. P. M. except in Upper Fitting Room

350 R. P. M. Upper Fitting Room

Steel Pressed Pulleys are most satisfactory

Transmission for Upper Fitting Room:

Link Silent Chain Belt

Spartan "V" Belts

Dust Collecting System:

Slow speed, high pressure is most economical

Location: outside of building if possible


20-22 Gauge Piping

Cost of Installation:


\$30-\$40 for every dust making machine, exclusive of motors

The kind of a Power Equipment that should be put in a shoe factory is a most important factor to consider. The generally accepted method of installation is with Short Drives and Electric Motors. The old-fashioned method of Long Line Drives belted from floor to floor and then to the engine is no longer modern or efficient.

On using the old Long Drives starting with large shafting at the engine end and gradually working down to the small



3 H. P. MOTOR REPLACING "MULE STAND DRIVE" SPRINGFIELD SHOE WORKS



5 H. P. MOTOR DRIVING 12 HAND METHOD LASTING MACHINES AND 4 REX PULLING-OVER MACHINES

Old Method "pipe-stem" shafting, an enormous amount of power is wasted in frictional load for turning the shafting alone, and waste of power means waste of coal and coal is expensive.

By the use of electric motors and short drives, we have the most flexible kind of an outfit, and if increases of output New Method are contemplated this flexibility works out very simply by the addition of new or larger motors, while with the steam-driven plant an increase in the output requires a large investment for the new requirements.

Type of Motors


The Alternating Current type of motor of 550 volts, 3-phase and 60-cycle, has proven the most satisfactory.

The 550-volt circuit requires less cost to install on account of the small size wire which can be used, and this high voltage


High should not be more dangerous than a lower one, provided that the necessary safety appliances, such as oil switches and up-to-date methods of wiring, are used; and as this high voltage current will demand such devices, this voltage really proves less dangerous than a lower one.

Alternating Current Motors are most satisfactory, due to the intermittent factor of Shoe Machinery, and motors of Alternating Current this type can be depended upon to take care of instantaneous overloads where Direct Current Motors would be soon damaged by such abuse.

A most important question next comes up as to whether it is feasible to buy or manufacture electric current. Generally speaking, unless one has a requirement of 100 horse power, it is best to buy, and for a larger requirement to install a power plant of his own, unless the Central Power Station rate is very low indeed. This is a case for figuring. It should, however, be borne in mind that a factory must be heated, and to heat a building and furnish certain machines with steam, a boiler must be operated and at high pressure, for the Goodyear Wax Thread Machines require a pressure of from thirty-five



100 K. W. ALTERNATING CURRENT CURTIS STEAM TURBINE



750 K. W. TURBINE

to forty pounds; and when one has such a boiler or boilers they should be worked to their capacity in order to show true economy.

The Curtis type of turbine engine is a most satisfactory installation for a 100 K. W. requirement or over. It is simple

Turbine and compact in design, and is economical as well as being modern in construction.

The Bleeder type permits of the taking of the exhaust steam after its first stage in sufficient quantities to insure the proper heating of the building.


There are several types of condensing outfits on the market for use in connection with the turbine, and the engineer in

Condensers

charge should be best informed as to which type would be most suitable in each instance.

Other Power Units

For smaller requirements than 100 K. W. a direct connected generator with a reciprocating steam or gas engine might best answer the needs of a manufacturer.



DIRECT CONNECTED GENERATOR SET AND SWITCH BOARD

· Cost of Power The cost of making or buying current should not exceed two or two and one-half cents per K. W., except when purchased in

small quantities.

The artificial lighting of a factory is a feature which has been the subject of considerable study during the past few years, and experience has proven that, under most conditions, it is possible to provide sufficient light by means of general illumination properly located rather than by specific lights for each machine.

Shafting 1½ inches in diameter throughout the plant, with the exception of the Upper Fitting Room, seems to be rather an ideal condition. This should be put up in units of 60 feet, and located 18 inches from the wall and have a span of 8 feet between the boxes, 10 feet being the limit for any span which we should recommend.

Sells Roller Bearings are ideal for the boxes, as this type of bearing reduces the frictional load to about 25 per cent, whereas with Babbitted Boxes the frictional load, under the best installations, seldom betters 40 per cent. A 10 or 12 inch drop to the hangers should warrant a satisfactory condition.

The shafting should run 300 revolutions per minute, except in the Upper Fitting Room, for at this speed the Driving Pulleys average a convenient size, and the belt lengths to the various machines are not excessive.

Pulleys

Pulleys

Pulleys


Pulleys

The first cost is a fraction more, the satisfaction and wear are worth the difference.


The Upper Fitting Room Millwrighting is special owing to the type of bench most universally used, and to the high speed of the upper sewing machines. The shafting should be 1-\frac{3}{16} inches in diameter, and should run at 350 revolutions per minute. The shafting should be connected with motors by a silent chain belt to insure a uniform speed under

all conditions. The Spartan "V" Belt can be conveniently used in connecting two or more benches where a separate motor for each bench is not practical.


A slow speed, high pressure, dust collecting system is an economical method of taking care of the dust problem. The collector should be located convenient to the Dust power house, and the piping should, if pos-Collecting sible, be on the outside of the building. This seems the logical location, owing to the fact that when it is put on the inside of the building it takes up too much room. In placing it on the outside it is necessary to use a somewhat heavier gauge piping, and this should, of course, be kept painted in order to make it weather-proof. A rough way of figuring the cost of installing a dust collecting system is to figure from \$30 to \$40 for each dust making machine; this figure does not include the cost of the motors for driving the fans.




LINK BELT INSTALLATION IN UPPER FITTING ROOM




PLAN OF UPPER FITTING TABLES CONNECTED WITH SPARTAN OR LINK "V" BELTS



OVERHEAD EXHAUST SYSTEM



TWO EXHAUST FANS ON OUTSIDE WALL, ENDICOTT, JOHNSON & COMPANY




"SELLS" ROLLER BEARING BOXES WITH SINGLE ROLLER STRUCTURE FOR LINE SHAFTS AND COUNTER SHAFTS

In operating a manufacturing plant, there is no one item of expense of more importance than that of the "friction load" of the power-transmitting machinery.

That this "friction load" can be reduced from 25% to 50%, depending upon load, speed, etc., has during the past seven years been proven beyond any possibility of doubt the only question remaining to be determined being the type of Roller or Ball Bearing it is desirable to use.

A series of tests and actual use, for a period of six or seven years, has demonstrated that a Roller Bearing is better than a Ball Bearing for transmitting power in a mill driven by steam, water or electricity.



CARTON MAKING EQUIPMENT

THE AUTOBOX CARTON SYSTEM

The Autobox Carton System is particularly valuable to shoe factories because it assures quality, convenience and economy.

The box is made from a single piece of boxboard, the corners of which are retained, and folded across inside the ends, thereby doubling the ends and making them the strongest and stiffest part of the carton.

Shoe manufacturers give away a carton with every pair of shoes sold.

Carton cost is, just as legitimately as the leather cost, a part of the cost of making and marketing shoes. Therefore any saving in carton cost is just as vital; and in most shops the saving is easier to make.

The manufacture of acceptable shoe cartons is not a single operation employing a single machine, but a progressive operation involving several processes.

The first operation is the preparation of the box blank, which is cut out and scored at one operation on a cutting and creasing press. Next follow the gluing, folding and setting up, which are performed automatically at one operation by the Autobox, and which completes the shell of the box.

The blank for the lid is cut and scored by the same method and on the same machine as the box blank — the die being changed, of course. The lid blank is folded by hand or by machine as may be desirable, according to the output, and is "stayed" at the corners with Manila or Kraft Stock, on a Staying Machine, thus completing the shell of the lid.

Both box and lid shells are then "stripped" with glazed or colored paper, the operation being performed on "Stripping Machines," of which there are several types, adapted to the different requirements of different shops; and the lid is "topped" on a "Topping Machine," usually with paper the same as the strip. These operations cover the edges of the blank and give a finished carton.

Machines for mixing the adhesives, for slitting the covering paper and for baling the waste are usually made a part of the carton plant.

The power required for the operation of the plant is comparatively slight, amounting to not more than three or four horsepower in a 10,000 pair plant. Live steam from a half-inch pipe is desirable for heating and mixing adhesives; but if this is not conveniently obtainable, cold adhesives may be used at but little difference in cost.

The employees, excepting for blanking and for the Autobox, are usually women, and most of the operations are paid for on a piece basis.

HANDY REFERENCE FIGURES

Steam requirements in pounds for heating:

Goodyear Stitchers		 35-40 lbs.
Goodyear Welters		 35-40 lbs.
McKay & Richardson	Sewers	 40 lbs.
Bottom Driers		35 lbs

Cost of heating a factory by steam in a climate like New England: approximated

3 cents to 4 cents per square foot of floor space per season. Boiler cost:

200 pounds pressure Babcock & Wilcox Co., about \$16.00 per horse power

International Engineering Works, Ltd., about \$11.00 to \$13.00 per horse power.

These prices do not include piping, but do include delivery and setting

Motor cost:

From \$16.50 to \$20.00 per horse power

Turbine cost:

A. C. condensing type with exciter

100 K. W	\$4400.00
200 K. W	6700.00
300 K. W	8000.00
500 K. W	9600.00
Average price per K. W	26.00

Switchboard cost about \$300.00

Condensers (Jet Type):

Cost from \$1100 for 100 K. W. Turbine up to \$2500 for 500 K. W. Turbine.

Cost of power equipment including boilers, turbine, switch-board, condenser, and motors, but not piping, building or smoke-stack, from \$80.00 to \$90.00 per horse power.

Note: These above prices are average costs only and are subject to change with the market.

Relations of the size and speeds of driver and driven pulleys:

NOTES

NOTES

STANDARD APPLIANCES FOR USE IN SHOE FACTORIES

In the past few years the importance of standardized equipment has been demonstrated to a large extent by the demand of manufacturers for indestructible appliances. The metal bench legs, metal racks and other such devices, seem to fulfill this demand most successfully. These metal fixtures become an asset to the manufacturer rather than a liability; for they will wear indefinitely, are practically fireproof, and because of the fact that they are collapsible they are easily taken care of when not in use. These racks, tables, etc., are made up in standard sizes, and, if so desired are made movable with the best type of non-clogging casters or truck wheels; thus making for the greatest convenience.

Stock racks are made up in standard size units so that from

Stock Racks

time to time, as the demands increase, new units may be added and the continuity of the stock room maintained.

In most departments of a factory certain hand operations require the use of a table or bench. Much can be said to Tables

condemn the old practice of using a continuous bench for these operations, which consume the best light in the less up-to-date factories, and where the amount of bench space required depends largely on the operator's disposition. The individual table takes care of these objections when properly located. Its many uses determining its indispensability, are as follows:

Cutting Room: Inspecting, sorting, matching, painting, piecing stays and marking vamps.

Sole Leather Room: Inspecting, sorting, doubling, etc.

Stitching Room: Cementing, folding, ironing edges, blacking edges, marking for buttonholes, lacing, buttoning, trimming and inspecting.

Finishing and Packing Room: Ironing, cleaning, staining, painting bottoms, inking edges, sock lining, repairing tips and vamps, bow attaching, vamp ironing and creasing, lacing and buttoning, inspecting and packing.

Fixed benches are an important fixture in a shoe factory, and a standard metal bench leg has been designed for the convenience of the shoe manufacturer. These are made in two lengths — one for a bench where the operator sits down and the other where he stands up at his work. The expense of these is so slight that the use of wooden joists can hardly ever be considered. Metal legs can be used innumerable times, are always ready for use and make a much neater appearance than wood. The expense of finding a carpenter and looking for material is a decided nuisance as well as a needless expense.

Many operations, such as sorting, stacking soles and counters, etc., have in the past been done on fixed benches

Mobility of Equipment

or tables, so that the work must be handled several times before it reaches its destination; such as packing and unpacking on trucks. Movable Cut-sole Racks, Movable Sorting Tables, etc., do away with this unnecessary handling by just pushing the table or rack directly to the operator.


Movable Last and Form Racks, Shank Racks, Last Boxes, Upper-carrying Racks, Bag Holders, etc., are helping to carry out this idea of reducing unnecessary handling, which prevents the liability of loss of pieces and the danger of mixing sorted parts, as well as loss of time.

On the following pages will be found illustrations which depict the various types of equipment which have been described in the preceding paragraphs. They also give an excellent idea of the range of uses in which this equipment has already found a place.




METAL SHOE RACK








NON-CLOGGING CASTOR




LONG DOWEL SHELF




TREEING-ROOM SHELF



PARTITION SHELF (Long Dowel) WITH COVER



SHOE RACK FITTED WITH COMBINATION PIN PARTITION SHELVES



SHANK RACK



"STAND-UP" FLOOR POST



"STAND-UP" FLOOR LEGS




FLOOR BRACE



WALL BRACKET



"SIT-DOWN" FLOOR LEGS



CUT-SOLE RACK



MOVABLE BAG HOLDER




MOVABLE STOCK TABLE




INDIVIDUAL WORK TABLE



UNIT STOCK RACK



UPPER CARRYING RACK




CEMENTED SOLE TRAY RACK




MOVABLE LAST RACK

43



PACKING AND NAILING RACK



INDEX

App	nances, Standard, 16	or (Jse	ın :	ono	ега	acto	ories	3			34
	rings											23
	ings, "Sells Roller"											27
	, "Link" Installatio						_					24
Belt	, Plan of Upper				able	es c	oni	rect	ed	wit	h	
	Spartan "V" — Illi											25
Ben	ches										•	35
												6
Buil	ding, The Light of	a										10
Buil	ding, Material of											ΙI
Buid	lling, Size and Shap	e of										8
	ons, Equipment for											28
	on System, Autobo											28
	densers											22
Dus	t, Collection of .											24
End	icott-Johnson "Scou	ıt''	Fac	ctor	y —	- III	ust	rati	on			9
Equ	ipment, Mobility of											35
Exh	aust Fans, Two on	Out	side	e W	all-	— I	llu:	stra	tion	l .		26
Exh	aust, Overhead Syst	em		Πlι	istra	atio	n					25
Figu	res, Handy Referen	ce										30
F1oo	rs, Altitude of .											10
Floo	r, Plan, Ideal Shoe	Fac	tor	У								7
Hos	oital at Plant of US	MC	, B	evei	ly -	I	llus	trat	ion			13
	nidifying Room											14
Hun	nidifying Room — I	llus	tra	tion								15
	trations, Miscellane									d		
	Brace, Floor .											39
	Bracket, Wall .											39
	Castor, Non-Cloggi											36
	Holder, Movable B	ag										40
	Legs, Table, "Sit-D	ow:	n"									40
	Legs, Table, "Stand	1-U	p"									39
	Post, "Stand-Up,"	Flo	or									39
	Rack, Cement Sole											43
	Rack, Cut Sole .											40
	Rack, Movable Las	t										43


INDEX (Continued)

musua	tions, i	VIISCE	папс	ou	s. (•	JOI	LIII	ueu	.)				
Ra	ck, Pac	king	and	Na	ilin	g							
Ra	ck, Sha	ınk											
Ra	ck, Sho	e, Co	mbi	nat	ion	Pir	ı, F	art	itio	n Sl	nel v	es	
	ck, Sho												
Ra	ck, Sho	e, M	etal										
Ra	ck, Uni	it Sto	ck										
Rae	ck, Up	per C	arry	ing									
She	elt, Lon	ig Do	wel										
She	elf, Par	tition	L (VV:	ith	Co	ver,)						
She	elf, Tre	eing l	Roor	n									
Tal	ole, Ind	lividı	ıal V	Vor	k								
Tal	ole, Mo	ovabl	e Sto	ck									
Lighting	ζ.												
Light a	nd Pow	er, S	ynor	sis									
Locker a	and Wa	ash R	oom	U:	SM	C, I	Bev	erl	y —	- I11	ustı	atio	on
Millwrig													
Millwrig													
Motors,	Altern	ating	Cu	rer	nt								
Motors,	High '	Volta	ge										
Motor,	Three	H.P.	, Re	olac	eing	"I	Mu	le S	Stan	d I)riv	e"	
Illu	stratio	n .											
Motor,													
	chines												
	stratio						-						
Motors,													
Offices													·
Power													
Power a	nd Lig	ht. S	vnor	sis									
Power,	Cost of												
Power F	Plant. (Cost o	of										
Power,	Other 1	Unite	S										
Pulleys													
Racks,													
Sash In	inton S	Steel f	or S	de	Wa	11c .		T1111	etro	tio	1		

INDEX (Continued)

Sash, Pond Continuous, at	nd S	awto	oth	Roc	f		
Illustration							12
Shafting, Speed of							23
Storage, of Material							13
Tables, Cutting Room							34
Tables, Finishing and Packing	Room	n					34
Tables, Sole Leather Room.							34
Tables, Stitching Room							34
Tower							10
Transmission, New Method							20
Transmission, Old Method							20
Turbines							22
Turbine, 100 K.W. Alternating	g Cui	rent	Curt	is St	ean	1	
— Illustration							21
Turbine, 750 K.W. — Illustrat	ion .						21
Welfare, Employees'							13
Windows							









LIBRARY OF CONGRESS
0 005 344 428 3 ●